

VELO HINGE

[BIKE HOOK / VERTICAL STORAGE]

INSTRUCTIONS

Velo Hinge must be mounted to a wall stud.

1. Locate wall stud, position the center of Velo Hinge 6 feet (2 m) off the ground, mark the 3 screw holes. Hook should be on top. (Height can vary with bike size)
2. Drill 1/8" pilot hole on marks (IMPORTANT).
3. Mount unit to wall stud with the included screws.
4. Hang bike on hook to determine position of rear wheel.
5. Hold the Wheel Bumper where tire contacts the wall and mark position of the 2 screw holes.
6. Drill 1/8" pilot hole on marks (IMPORTANT).
7. Mount Wheel Bumper with the included screws.
8. Tighten the Hinge Bolt to set desired swing friction.

HINGE DIRECTION


Before the hook is mounted to the wall, the Velo Hinge can be set to swing to the left or to the right.

The hook is positioned at the top of the Velo Hinge.

1. With a 5 mm hex-wrench loosen and remove the Hinge Bolt on the left side of the unit. Be careful not to lose the plastic spacers. Separate the two sides of the hinge.
2. Slide the hook out of the face plate and re-install it into the opposite side. Rotate the face plate 180°.
3. Rotate the back plate 180° and put the sides back together.
4. The hole for the Hinge Bolt should now be on the right.
5. Re-install and tighten the long bolt to complete the hinge.
6. Tighten the Hinge Bolt to set desired swing friction.

5 MOUNTING SCREWS AND
1 WHEEL BUMPER INCLUDED

HOOK FOLDS OUT



WHEEL BUMPER
PREVENTS THE
BIKE FROM
SWAYING

HOLDS 1 BIKE
VINYL COATED HOOK
POWDER COATED STEEL
LOAD CAPACITY: 50 LBS (23 KG)
NO ASSEMBLY REQUIRED
3-YEAR WARRANTY